

UD4800 Connection Kit Assembly



To Create a UD9600 Dolly:

Step 1: Remove Top Pads.

Step 2: Add the Red Connectors to the tops of the Dolly and place the large bolts through with the black side on the top.



Step 3: Insert Top Pads in center hole of Red Connection Bar.

Step 4: Connect the two silver connector rods using the smaller silver rod and two cotter pins. Connect them to the dollies using the large bolts. Secure the bolts underneath.

Step 5: Add the remaining two cotter pins to the outer edges of the silver connector rods. Your dolly connection kit is now complete.

To Create a Single Wheel Dolly: (4800 lb. Capacity)

Step 1: Follow steps 1-3 above on one dolly only.

Step 2: Connect one silver connector rod to the dolly using two cotter pins (one on each end).

