



Part# 11666 - Siphon Foot Pedal & Gun Kit Assembly Instructions

Part #	Description	Quantity
11595	Siphon Gun Pressure Hose (4')	1
11596	Foot Pedal Pressure Hose (6')	1
11594	Foot Pedal Assembly	1
11632	Foot Pedal Valve	1
11606	1/4" Pipe Coupling	1
10188	1/2" Washer	2

1. Install male end of 4' pressure hose to air inlet on siphon gun body. Insert other end of 4' pressure hose through (1) 1/2" washer and then insert male end of pressure hose through air inlet hole on cabinet from the inside. Next, install (1) 1/2" washer on the outside of cabinet on male end of pressure hose, then install 1/4" pipe coupling and tighten.
2. Install one end of 6' pressure hose to 1/4" pipe coupling on outside of cabinet (previously installed) and tighten.
3. Install other end of 6' pressure hose to the foot pedal valve on the outlet marked "OUT". Compressed air supply will be installed on inlet marked "IN", foot pedal valve outlet marked "EXHAUST" must always be kept open.



DIVISION OF S&H INDUSTRIES
5200 Richmond Road • Cleveland, OH 44146
Phone 216-831-0550 • Toll Free 800-253-9726 •
Fax 216-831-9573
www.shindustries.com
E-mail: www.service@shindustries.com